

92

PLEASE ENTER YOUR
PIN NUMBER AND
THEN PRESS #
PRESS * TO CLEAR

FIG 15

ACTION

- USER INPUTS PIN AND
THEN #

94

PLEASE INSERT
STORED VALUE CARD
INTO READER AS
FAR AS IT WILL GO.

FIG 16

ACTION

- USER INSERTS STORED VALUE
CARD

96

SORRY, WE ARE
UNABLE TO PROCESS
YOUR TRANSACTION

FIG 17

ACTION

- MACHINE RETURNS TO FIRST
SCREEN AFTER TIME OUT.

FIG 18

10

PLEASE INPUT AMOUNT
BY PRESSING KEYS
THEN PRESS #
MAXIMUM \$100

ACTION

- USER INPUTS AMOUNT
AND #
EXAMPLE \$100 INPUT

FIG 19

108

\$100 FROM
CREDIT CARD
PRESS "YES" TO CONFIRM
"NO" TO INPUT NEW AMOUNT

ACTION

- CUSTOMER PASSES
APPROPRIATE BUTTON
EXAMPLE "YES"

09432710-144255

Fig 20

110
NOW PRINTING
VOUCHER FOR YOUR
CASH

ACTION

- PRINTER PRINTS VOUCHER

Fig 21

112
PLEASE PRESENT
VOUCHER INSIDE
TO RECEIVE YOUR
CASH.

ACTION

- USER TAKES VOUCHER TO
CASH REGISTER / CASH DISPENSER
ON WINDOW AND RECEIVES CASH

Fig 22

114
REMEMBER TO TAKE
YOUR VOUCHER

ACTION

- USER TAKES VOUCHER

Fig 23

Acrid

- MACHINE DISPENSES CASH

Fig. 2.4

אברהם

- VISA TAXES CASH

[illegible]

09439718-11299




FIG 25

192

FIG 26

PAY BY

1 CARD

2 CASH

ACTION

- USER SELECTS CASH OR CARD
- EXAMPLE CASH

194

FIG 27

INSERT BILLS INTO
BILL ACCEPTOR BELOW

PRESS "1" TO RETURN TO
FIRST SCREEN

ACTION

- USER INSERTS NOTES INTO
NOTE ACCEPTOR OR RETURNS
TO BEGINNING
- EXAMPLE - NOTE INPUT

196

FIG 28

AVAILABLE CREDIT

\$ 20.00

PRESS "1" TO RETURN TO
FIRST SCREEN

PRESS "2" TO BEGIN PUMPING

ACTION

- USER INSERTS MORE NOTES
OR PASSES OTHER OPTIONS
- EXAMPLE - USER PASSES "2."

198

FIG 29

REMOVE NOZZEL
AND PUMP GAS

ACTION

- USER REMOVES NOZZEL AND
PUMPS
- PUMP STOPS WHEN AVAILABLE
CREDIT IS REACHED OR
CUSTOMER SHUT OFF

09430718-14050

200

Fig 30

YOUR AVAILABLE
CREDIT IS GREATER
THAN YOUR CHARGE
A CASH VOUCHER FOR
THE DIFFERENCE IS
PRINTING

Action

- MACHINE PRINTS VOUCHER
FOR DIFFERENCE

202

Fig 31

PLEASE PRESENT
VOUCHER INSIDE
TO RECEIVE YOUR
CASH

09435710 11250




Fig 32




Fig 33





Fig 36





Fig 37







FIG 38

204







212

FIG. 39

FIG. 39



228



09439718-11209






FIG 40

094339718-111209



09430718-11359



3 - Select transaction

212

FIG 42

McDonald's logo

Your order total is:

Big Mac	\$1.99
Large Fry	\$1.29
Large Fry	\$1.29
Large Drink	\$1.33
tax	\$0.35
Total	\$6.25

Is this correct?

Yes

No

Need assistance?
 ◀ **Press here**


250

242

246

FIG 43


09439718-111399



5b - Cash withdrawal
(non-financial customer)

5a - Cash withdrawal
(financial customer)


0043918-11200



6 - Thank You


FIG 45

08439718-11200




6 - Thank You


FIG 46




1 - Insert card




2 - Enter PIN




3 - Select transaction



4 - Order total



5b - Cash withdrawal
(non-financial customer)



6 - Thank You




Fig 48





FIG 49

29-1

SECRET-87/66460

COD and Menu Board
Speaker
ATM interface
(select payment method,
and/or request cash withdrawal)
Cashier
Fulfillment



306

FIG 50

66211-81266460

COD Menu Board ATM interface
(place order by speaker, select payment
method, and/or request cash withdrawal)

Cashier
(if paying with cash)

Fulfillment




FIG 51




Fig 52

328






FIG 53

[illegible]


09430710-11200



378 →

Fig 55

09430718-11200



094330710 442000





FIG 57



6627-0126460




FIG 59




FIG 1




Fig 2




FIG 3

Action.
- SELECT "PAY INSIDE"




FIG 4

ACTION
- REMOVE NOZZLE
AND PUMP




FIG 5

Action
- NO RESPONSE
- REPLACE NOZZLE





FIG 6

ACTION
- USER PAYS INSIDE


FIG. 7



ACTION

- USER SELECTS "PAY OUTSIDE"


FIG. 8



ACTION

- USER SELECTS INPUT
FOR EXAMPLE "1" FOR
CREDIT CARD


FIG. 9



ACTION

- USER INSERTS CARD
AND WITHDRAWS CARD

FIG. 10



ACTION

- REMOVE NOZZEL AND PUMP

98
WOULD YOU
LIKE TO
HAVE SOME CASH?
IF SO PRESS "YES"

Fig 11

ACTION

- NO RESPONSE
- REPLACE NOZZLE

100
WOULD YOU LIKE
A RECEIPT?
PRESS
"YES" OR "NO"

Fig 12

ACTION

- USER PRESSES SELECTED KEY
EXAMPLE "YES"

102
RECEIPT IS NOW
PRINTING

Fig 13

ACTION

- PRINTER PRINTS RECEIPT

104
THANK YOU
PLEASE TAKE RECEIPT

Fig 14

ACTION

- USER TAKES RECEIPT